

LISTA DE MODELOS SOPORTADOS PARA JTAG.



Nota: Si ve algún modelo q no esté en la lista por favor contáctese con soporte@gsmunlock.com.co para solicitar información

Alcatel models:

- Alcatel OT255C
- Alcatel OT990
- Alcatel OT995

Haier Models:

- Haier C2010
- Haier C2040
- Haier C2076
- Haier C300
- Haier C3010
- Haier C301R
- Haier C5100
- Haier C6000

HTC Models:

- HTC 7Pro
- HTC 8S
- HTC 8X16GB
- HTC 8X8GB
- HTC Amaze4G
- HTC Artemis
- HTC Athena

- HTC ChaCha
- HTC Chief
- HTC Click
- HTC Dash
- HTC Desire
- HTC DesireCDMA
- HTC DesireC
- HTC DesireHD
- HTC DesireS
- HTC DesireV
- HTC DesireX
- HTC DesireZ
- HTC Diamond
- HTC Dream
- HTC DroidDNA
- HTC DroidEris
- HTC Elf
- HTC Espresso
- HTC Evo3DCDMA
- HTC EVO3D
- HTC EvoDesign4G
- HTC EvoView4G
- HTC Explorer
- HTC Explorer
- HTC Flyer4G
- HTC Flyer
- HTC Flyer
- HTC Gene100
- HTC Glacier
- HTC HD
- HTC HD2
- HTC HD7
- HTC HD7Pro
- HTC HDMini
- HTC Herald
- HTC Hero
- HTC Imagio
- HTC IncredibleS
- HTC Incredible-2
- HTC Incredible-C
- HTC Incredible-S
- HTC Inspire
- HTC Jade
- HTC JetStream
- HTC Jewel
- HTC Legend
- HTC Magic32A

- HTC Magic32B
- HTC Magic
- HTC Mega
- HTC Mozart
- HTC MyTouch4G
- HTC Neon
- HTC Nexus
- HTC Niki
- HTC OneS3
- HTC OneS4
- HTC OneV
- HTC OneXL
- HTC OneX
- HTC Polaris
- HTC Radar
- HTC Raphael
- HTC Rezound
- HTC Rhodium
- HTC RhodiumW
- HTC Rhyme
- HTC Sensation4G
- HTC SensationXL
- HTC Sensation
- HTC Snap
- HTC Supersonic
- HTC Surround
- HTC Tattoo
- HTC Thunderbolt
- HTC Titan
- HTC Topaz
- HTC Trophy
- HTC Vivid
- HTC WildFire
- HTC WildfireS
- HTC WildfireSCDMA
- HTC Wings
- HTC Wizard
- HTC Desire SV T326e (HTC Magni)
- HTC J ISW13HT (HTC Valente)

Huawei Models:

- Huawei C2605
- Huawei C2607
- Huawei C2801
- Huawei C2806M
- Huawei C2807

- Huawei C2808
- Huawei C2809
- Huawei C2823
- Huawei C2830
- Huawei C2856
- Huawei C2901M
- Huawei C2905
- Huawei C2906
- Huawei C31
- Huawei C3200
- Huawei C3500
- Huawei C5005
- Huawei C5100
- Huawei C5589
- Huawei C8500
- Huawei E153U
- Huawei E1550
- Huawei E160
- Huawei E160G
- Huawei E169
- Huawei E17X
- Huawei E220
- Huawei E5830
- Huawei E5832
- Huawei E585
- Huawei EC1260
- Huawei EC189
- Huawei ETS2205
- Huawei ETS2222
- Huawei ETS2225
- Huawei S7
- Huawei U1270
- Huawei U1280
- Huawei U2800
- Huawei U8110
- Huawei U8150
- Huawei U8150D
- Huawei U8160
- Huawei U8180
- Huawei U8220
- Huawei U8350
- Huawei U8350-51
- Huawei U8500
- Huawei U8650
- Huawei U8655
- Huawei U8800
- Huawei U8800Pro

- Huawei U8815
- Huawei U8825D
- Huawei U8860

LG Models:

- LG C660H
- LG CU720
- LG E400
- LG E405
- LG E510
- LG E612
- LG E615
- LG E900
- LG F100S
- LG F120K
- LG F120L
- LG F160K
- LG F160L
- LG F160S
- LG GM730
- LG GT540
- LG LS970
- LG LSP450T
- LG P350
- LG P500
- LG P698
- LG P705
- LG P930
- LG P970
- LG P999
- LG RD3000
- LG RD3100
- LG RD3500
- LG RD3510
- LG RD3540
- LG RD3610
- LG RD3640
- LG RD6100
- LG SH860
- LG SU630
- LG TD636
- LG VM265

MicroMax models:

- Micromax C100

- Micromax C111
- Micromax MMX250C

Motorola Models:

- Motorola W150i
- Motorola W200
- Motorola W210

Nokia Models:

- Nokia 1006
- Nokia 1255
- Nokia Lumia 610

Pantech Models:

- Pantech A730S
- Pantech A760S
- Pantech A770K
- Pantech A800S
- Pantech A810S
- Pantech A820L
- Pantech A830K
- Pantech A830L
- Pantech A830S
- Pantech A840S
- Pantech A850K
- Pantech A850L
- Pantech A850S
- Pantech T100K
- Pantech UM150
- Pantech UM175

Samsung Models:

- Samsung A837
- Samsung A867
- Samsung A877
- Samsung A887
- Samsung A900
- Samsung B119
- Samsung B139
- Samsung B159
- Samsung B209
- Samsung B219
- Samsung B259

- Samsung B2710
- Samsung B309
- Samsung B319
- Samsung B339
- Samsung B379
- Samsung B5330
- Samsung B5510
- Samsung B619
- Samsung B6520
- Samsung B7320
- Samsung B7330
- Samsung B7510
- Samsung C5510
- Samsung C6712
- Samsung E110S
- Samsung E120L
- Samsung E120S
- Samsung E160K
- Samsung E160L
- Samsung E189
- Samsung E329I
- Samsung F219
- Samsung F480
- Samsung F500
- Samsung F619
- Samsung G800
- Samsung G810
- Samsung i450
- Samsung I500
- Samsung I509
- Samsung i520
- Samsung I535
- Samsung I5500
- Samsung i550
- Samsung I5510
- Samsung I559
- Samsung i560
- Samsung I5700
- Samsung I5800
- Samsung i607
- Samsung i710
- Samsung I717
- Samsung i718
- Samsung I727
- Samsung i740
- Samsung i740
- Samsung I747

- Samsung I747M
- Samsung I7500
- Samsung I777
- Samsung i780
- Samsung I8000
- Samsung I8000L
- Samsung I8150
- Samsung I8160
- Samsung I8190
- Samsung i8320
- Samsung I8350
- Samsung i8510
- Samsung I8530
- Samsung I8700
- Samsung i8910
- Samsung I897
- Samsung I9000
- Samsung I9001
- Samsung I9003
- Samsung i900
- Samsung i900
- Samsung I9020A
- Samsung I9020T
- Samsung I9023
- Samsung I9070
- Samsung I9070P
- Samsung i908E
- Samsung I9100
- Samsung I9100G
- Samsung I9100GX
- Samsung I9100P
- Samsung I9103
- Samsung I9105
- Samsung I9108
- Samsung I9108X
- Samsung i910
- Samsung I917
- Samsung I920
- Samsung I920
- Samsung I9210
- Samsung I9220
- Samsung I9300
- Samsung I997
- Samsung L760
- Samsung M110S
- Samsung M130K
- Samsung M180S

- Samsung M180W
- Samsung M190S
- Samsung M200K
- Samsung M200S
- Samsung M240S
- Samsung M569
- Samsung M7500
- Samsung M7600
- Samsung M820
- Samsung M828
- Samsung M8800
- Samsung M8910
- Samsung N7000
- Samsung N8010
- Samsung P1000
- Samsung P1000N
- Samsung P1010
- Samsung P3100X
- Samsung P3110X
- Samsung P3113X
- Samsung P5100X
- Samsung P5110X
- Samsung P5113X
- Samsung P6200
- Samsung P6800
- Samsung P6810
- Samsung P7320
- Samsung P960
- Samsung R530
- Samsung S109
- Samsung S189
- Samsung S239
- Samsung S3310
- Samsung S3370
- Samsung S359
- Samsung S3850
- Samsung S5230
- Samsung S5250
- Samsung S5260
- Samsung S5300
- Samsung S5301
- Samsung S5360
- Samsung S5380
- Samsung S5380D
- Samsung S5510
- Samsung S5560
- Samsung S5560i

- Samsung S5570
- Samsung S5570i
- Samsung S5600
- Samsung S5660
- Samsung S5670
- Samsung S5750E
- Samsung S5830
- Samsung S5830G
- Samsung S5830i
- Samsung S5830L
- Samsung S6012
- Samsung S6102
- Samsung S6312
- Samsung S6500
- Samsung S6500D
- Samsung S6802
- Samsung S6810P
- Samsung S7070
- Samsung S7230E
- Samsung S7250D
- Samsung S7330
- Samsung S7350
- Samsung S7350i
- Samsung S7500
- Samsung S7500L
- Samsung S7500T
- Samsung S7530
- Samsung S7562
- Samsung S7562I
- Samsung S8000
- Samsung S8300
- Samsung S8500
- Samsung S8530
- Samsung S8600
- Samsung SC-05D
- Samsung SC-06D
- Samsung SPH-D700
- Samsung SPH-D710
- Samsung SPH-L710
- Samsung T479
- Samsung T499
- Samsung T589
- Samsung T669
- Samsung T679
- Samsung T749
- Samsung T759
- Samsung T879

- Samsung T919
- Samsung T939
- Samsung T959
- Samsung T959D
- Samsung T959V
- Samsung T989
- Samsung T999
- Samsung T999V
- Samsung U700
- Samsung U800
- Samsung U900V
- Samsung W299
- Samsung W629
- Samsung YPG1
- Samsung YPG70
- Samsung Z240
- Samsung Z500
- Samsung Z540
- Samsung Z630
- Samsung Z650i
- Samsung Z710
- Samsung ZV60
- Samsung GT-i9105 Galaxy S II Plus
- Samsung GT-i9082 Galaxy Grand Duos
- Samsung Gt-S5380k Wave Y

SonyEricsson Models:

- SE E15a
- SE U20a
- SE U20i
- SE X1
- SE X10
- SE X10Mini
- SE X8

Sierra Models:

- Sierra 597
- Sierra 801
- Sierra U595

Toshiba Models:

- Toshiba G810
- Toshiba G900 PDA
- Toshiba G910

- Toshiba TG01

ZTE Models:

- ZTE CN600
- ZTE AC2746
- ZTE AC2766
- ZTE AC30
- ZTE C335
- ZTE C370
- ZTE F160
- ZTE F280
- ZTE F285
- ZTE FWPC26
- ZTE MF100
- ZTE MF112
- ZTE MF170
- ZTE MF180
- ZTE MF180S
- ZTE MF190
- ZTE MF622
- ZTE MF626
- ZTE MF627
- ZTE MF628
- ZTE N721
- ZTE R518
- ZTE S100
- ZTE S160
- ZTE S1602
- ZTE S165
- ZTE S170
- ZTE S185
- ZTE Skate
- ZTE V880
- ZTE V889D
- ZTE V9
- ZTE WP829

Various brands and models:

- Acer S100
- Anydata ADU 555C
- ASUS P526
- CoolPad 5860Plus
- Daewoo DPN3500
- DELL Streak
- DELL XCD28

- Eten X800
- EuroSky ES4100
- Fly IQ285
- Intex In50
- iPAQ 614
- Lenovo LePhone3GW100
- LinkSys WRT54GL
- Olive C2110
- Orange Boston
- Orton 4100C
- Qtek 9000
- RoverPC EvoV7
- Sungil SXC1080
- Unicare ChivaC2
- Unicare UN510BF